

Iron hydroxide based products

FerroSorp®



Lucia Borrell

HeGo Biotec International GmbH

Portugal, 20.05.2025

1. Company introduction
2. Why iron hydroxides?
3. Water treatment
4. Gas treatment

For three decades, HeGo Biotec GmbH has gained extensive experience in treating gases and water



1 Introduction of HeGo Biotec GmbH

Member of the Fechter Group



1990 (HeGo), 2022 (HBI)



36 (HeGo), 50 (total)



- Berlin (Headquarter)
- Lincoln, RI, USA



Activities:	Water treatment	FerroSorp [®] SP, Plus, FerroSorp [®] RW
	Gas treatment	FerroSorp [®] DG, S

Iron hydroxide has a high binding capacity for various pollutants

2 Why iron hydroxides?

Iron hydroxide has a high binding capacity for:

- Phosphates (PO_4^{3-})
 - Arsenates (AsO_3^{4-} , AsO_4^{4-})
 - Heavy metal ions (Cu, Zn, Ni, Hg ...)
 - Sulphides (S^{2-} , H_2S)
- } Water phase
- } Water & gas phase

Iron hydroxide is superior to iron oxide because of:

- Bigger surface area (BET 20 - 70 vs. 180+ m^2/g)
- Higher reactivity

Water treatment

Products based on iron hydroxide for the separation of contaminants from aqueous solutions

3 Filter granulates: FerroSorp[®] SP, Plus, RW

Advantages:

- Natural substances
- High cleaning performance at low cost
- High loading rates due to a highly porous surface



Applications:

- Water remediation
- Drinking water
- Aquariums, lakes and fish farming
- Storm and rainwater treatment
- Leachate treatment
- Retention soil filters


Arsenic removal with a FerroSorp® Plus for municipal potable water

3 FerroSorp® Plus - Applications



Phosphate removal with a FerroSorp[®] Plus fixed bed adsorber

3 Applications for water treatment:



Restoration around the re-naturalization of the lake Orankeesee

3 Applications for water treatment:



26.05.2025

Environmental Protection - State of the Art

9

This information is confidential. The slides or any part of it must not be shared with 3rd parties without written approval of HeGo Biotec International GmbH.


Filter layer includes FerroSorp® RW

3 Applications for water treatment:




Use of FerroSorp® RW in open air rainwater infiltration with upstream sedimentation

3 Applications for water treatment:



Use of FerroSorp[®] RW in canister type filter vessel

3 Applications for water treatment:



FerroSorp® Plus is easy to handle, reduces cost and is available

3 Reference 1: Municipal Potable Water Treatment – Central Italy

Water flow	144 m ³ /h
Concentration	As 26 µg/L V 22 µg/L SiO ₂ 30 ppm
pH range	7 – 7.5
Water source	Various springs – seasonal plant (summer)
N° of filters	5
Configuration	Parallel
Diameter	1.6 m
Filling volume	4.0 m ³ each filter
Used product	FerroSorp® Plus
Advantages compared to the previously used product	Cost-effective Availability



FerroSorp® Plus is easy to handle, reduces cost and is available

3 Reference 2: Municipal Potable Water Treatment – Peru


Water flow	45 m ³ /h
Concentration	As 18 – 20 µg/L
Water source	WWTP
N° of filters	6
Configuration	Parallel
Diameter	1.6 m
Filling volume	5 m ³ each filter
Used product	FerroSorp® Plus
Pressure drop through the filters	0.1 bar on average



Gas treatment

Desulphurisation is needed for several applications

4 Overview about different applications



FerroSorp® DG is a cost-effective and well-proven solution for many biogas plants and other gases with H₂S

4 Desulphurisation with FerroSorp® DG and S series

Advantages of FerroSorp® DG:

- Stabilized biogas production
- Easy dosing
- No corrosion



Advantages of FerroSorp® S:

- Low removal costs for H₂S
- High loading capacities
- Reaches 0 ppm H₂S



We offer different solutions for the odour treatment

4 GoSens[®], GoSil[®] and FerroSorp[®] FS-1000

GoSens[®]: H₂S measuring device

- 0 – 1.000 ppm
- Data transmission
- Battery life up to 24 months



FerroSorp[®] FS-1000: Exhaust air filter

- Remove H₂S odour from any location
- With integrated compressor



GoSil[®]: Pumping station injection point

FerroSorp® S is not only cheaper, but also more convenient and causes less pressure drop

4 Reference 1: Landfill gas, Quebec, Canada

Gas flow	1,200 m ³ /h (706 scfm)
H ₂ S-concentration	1,250 ppm (later ≤ 4,000)
Relative humidity	c. 30 %
# of vessels	2
Arrangement	Lead / Lag
Dimensions (diameter x filling height)	1.8 m x 9.1 m (6 ft x 30 ft)
Filling volume per vessel	22 m ³
Used product	FerroSorp® Sk 5 - 25 mm
Advantages compared to the previously used product	<ul style="list-style-type: none">- No severe clumping / bridging- Shorter downtime during change-outs- Less costs per filling- Longer operating time- Lower pressure drop



FerroSorp® S causes much less pressure drop and removes H₂S more reliably and more consistently

4 Reference 2: WWTP gas, Singapore

Gas flow	2,400 – 4,500 m ³ /h (1,410 – 2,650 scfm)
H ₂ S-concentration	1,500 – 3,000 ppm
Relative humidity	c. 70 %
# of vessels	2 (below ground)
Arrangement	Parallel
Dimensions (diameter x filling height)	3.7 m x 7 m (12 ft x 23 ft)
Filling volume per vessel	73 m ³
Used product	FerroSorp® Sd 2 - 4 mm
Advantages compared to the previously used product	<ul style="list-style-type: none">- Much lower pressure drop: c. 140 mbar (2 psi) vs. 345 mbar (5 psi)- Maintains 0 ppm H₂S at the outlet much longer



FerroSorp® S is used to remove odour (esp. H₂S) from exhaust air from the sewer system

4 Reference 3: Odour removal, Germany

Gas flow	370 m ³ /h
H ₂ S-concentration	c. 350 ppm
Relative humidity	90 – 100 %
# of Vessels	1
Dimensions (Diameter x filling height)	0.95 m x 0.6 m
Filling volume	c. 0.4 m ³
Used product	FerroSorp® S 5 – 25, FerroSorp® Sd 2 - 4 mm and Activated carbon
Description	The air is treated with FerroSorp® S first to remove H ₂ S and then with activated carbon to remove VOCs



Thank you for your attention.

Please contact us, we gladly advise you individually!

Lucia Borrell

Account manager Portugal, Spain and Latinamerica

Phone: +49 30 84 71 85 96

Mobil: +49 152 377 94 349

E-Mail: lucia.borrell@hego-biotec.com

